



#### **DRYER FRONT PANEL AND DOOR PARTS**



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	692728	Harness, Door Switch	6 7		Door, Rear Door, Front	14 15	3389441	Handle, Door
1A	717253	(Includes Illus. 1A) Plug, Terminal (2–Way)			Almond	16		Almond
		(Connects With Main Dryer	9 10		Bearing & Seal Clip, Felt Pad (2)	18		Support Protector Screw, Console Strut Mounting
2		Harness) Switch, Door	11 12		Strike, Panel Screw, Door	19	694091	9
3 4	691581 692619	Lever, Door Switch Panel, Front White	40	242044	Switch Mounting (2)	20	348023	J ,
5	692620	Almond Seal, Door	13	343641	Screw, 10–16 x 1/2 (2) (Front Panel To Side Panel)			Door (2)


#### DRYER CABINET AND MOTOR PARTS



# **DRYER CABINET AND MOTOR PARTS**

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	660658	Clamp, Motor	20	3394652	Belt, Drive	32	354975	Screw & Washer (3)
		Mounting (2)	21	3396426	Pulley, Motor			(Lid Latch
		343481 (Alt.)			(60 Hz.)			Mounting)
_		685441 (Alt.)	22	691366		33	693304	
2	3398046		23	692771	,			(Transition Panel
		(60 Hz.)			Bracket To Base			To Closure)
4		Restrainer, Belt	24		Base, Dryer	34	697776	
5		Bracket, Motor	25		Nut, Push-In			(10-32 x 1/2)
6 7		Panel, Rear	26	692926	Cove, Transition	35		Screw, 10-16 x 3/8
		Screw, 10-16 x 1/2			Panel (Black)	36	357021	Capacitor, Motor
8	307972	Cover, Terminal	27		Panel, Transition			Start (Automatic
		Block		692933	White			Washer)
10		Panel, Side (L.H.)		692934	Almond	37	357030	Clamp, Capacitor
	3402293	White	28	692641	Top, Dryer	38	343641	Screw, Capacitor
	3402294	Almond	29		Panel, Side (R.H.)			Mounting
14	3399602	Elbow, Upper		3402287	White			(10-16 X 1/2)
15	3394083	Clip, Front		3402288	Almond	41	686770	Edge, Protector
		Panel (2)	30	693145	Latch, Lid	42	3388580	Cable
16	98234	Clip, Ground	31		Closure, Control	43	343641	Screw,
17	3399603	Elbow, Lower			Area			10-16 x 1/2 (2)
				692781	White	44	90296	
				692782	Almond			•

#### DRYER BULKHEAD PARTS




# **DRYER BULKHEAD PARTS**

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2		Screw, 10–16 x 1/2 Clip, Air Duct	29	685273	Cover, Lint Screen Outlet	37	693141	Clip, Wiring Harness (3)
		To Bulkhead	30	690997	Tri-Ring (4)	38	694018	Cord, Power
3	696529	Air Duct & Cover	31		Shaft, Drum	38a		Strain Relief,
5		Thermostat,			Roller (L.H.)			Power Cord
		Internal Bias	32	3397588	Roller, Support (2)	40	3388703	Washer, Support
8	3403140	Thermostat,	33		Washer, Support (4)	41		Screw Kit
		Heater Box	34	3359452	Nut, 3/8-16 (2)			(For Terminal
		205°F	35		Screw, 10-16 x 3/8			Block)
		96°C			(Bulkhead To	42	279318	Terminal, Tinned
9	3400800	Screw, 8-18 x 3/4			Base)			& Brass (3)
10	3398161	Clip, Heater Box	36	3398874	Harness, Main			(Includes Illus. 41)
		To Bulkhead			Dryer Wiring	43	697776	Screw, Ground (2)
11	697269	Heater Box			(Includes Illus.			(10-32 x 1/2)
13	339956	Seal, Air Duct			36A, 36B, 36C,	44	3390647	Screw, 8-18 x 1/2
		To Bulkhead			36D & 36E)	46		Screw, 8-18 X 3/8
14	696426	Wheel, Blower	36A	717252	Receptacle,	47		Fuse, Thermal
16	696658	Seal, Fan			Terminal (2-Way)	48	359702	Cap, Screw
		Scroll			(Connects With	49	255563	Clip, Strain
17		Fan Scroll			Door Switch			Relief
21	3399507	Shaft, Drum			Harness)	50	697439	Clip, Harness
		Roller (R.H.)	36B	697780	Receptacle,			To Duct (2)
22		Drum, Dryer			(Gas Valve)	52	345335	Cover, Manifold
23	3394508	Ring, Bearing	36C	62889	Receptacle,	53	347455	Support,
24	685207	Baffle, Drum (3)			Terminal			Heater Box
25	697777	Screw, Baffle			(2-Way)	54	3387208	Support,
		Mounting (6)			(Connects With			Corner Gas
		(11–16 x 7/8)			Automatic Console	55	697571	Guard, Sock
26	345648	Seal, Drum Rear			Harness)	56	3401796	
27		Bulkhead	36D	3395683	Receptacle,			(Refer to page 19
28	348399	Lint Screen			Multi-Terminal			For Complete
					(Connects With			Breakdown)
			l		Dryer Motor)			

#### **DRYER SUPPORT AND WASHER PARTS**


	Illus. No.	Part No.	DESCRIPTION
5 PRESURE SWITCH HOSE ROUTING	1 2	694304 692647	Cover, Channel Support, Dryer (L.H.)
HOSE ROUTING	3 4	343641 3400000	Screw, 10-16 x 1/2
1 6A 6A	<sup>5</sup>	692646	To Dryer Supports) Support, Dryer (R.H.)
	6	3388677	Harness, Upper (Automatic) (Includes Illus.
4	6A	696074	6A, 6B & 6C) Plug, Terminal (12–Way) (Connects With
7 6	6B	62889	Automatic Console Harness) Plug, Terminal (3–Way) (Connects With Automatic Lid
7 6B	6C	62505	Switch Harness) Block, Disconnect (Connects With Automatic Washer Motor)
13	7	3347812	Clip, Wiring Harness (4)
	11		Clip, Pressure Switch Hose (2)
WASHER MOTOR	12 13	693141 696238	Clip, Harness Hose, Pressure Switch
1/			

#### **WASHER TOP AND LID PARTS**



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
3	3398843	Lid White	12	384693	Top White	16	358684	Strike, Lid Switch
	3398844	Almond		384694	Almond	17	384459	Hinge, Lid (R.H.)
4	384475	Bumper, Lid (2)	13	19119	Bumper, Lid	18	274707	Screw, Ground
5	384458	Hinge, Lid (L.H.)			Hinge (2)			(10-24 X 1/2)
7	3351355	Screw, Lid Hinge Mounting (4)	14	21258	Bearing, Lid Hinge (2)	20	271166	Nut, Ground Screw (10–24)
9	692985	Clip, Spring (2) (Top To Cabinet)	15	3356311	Screw & Washer, Lid Switch Shield (2)	22 23		Switch, Lid Clip, Harness Routing

# **WASHER CABINET PARTS**



#### **WASHER CABINET PARTS**

Illus. No.	Part No.	DESCRIPTION
1	356746	Clip, Condenser
2	343641 62863	(2) Screw, 10–16 X 1/2 Screw, Mixing Valve Mounting (2)
5	3360389	(10–16 X 3/8) Valve, Water Mixing
6 7	370451 692699	Clamp, Hose Hose, Water Inlet (Siphon Break To Mixing Valve)
8	696013 696014	Cabinet White
9 10	3390046 696710	Almond Protector, Edge Hose, Drain
11 12	692400 660975	Nut, Push-In (2) Plug, Top To Cabinet 689587 (Alt.)
13 14 15 16 17 18	356739 660626 356471 356363 272861 696394	694010 (Alt.) Connector, Hose Clamp, Hose Cap, Siphon Break Siphon Break Clamp, Hose Hose, Water Inlet (Siphon Break To
19 20 22 23 24	367594 358594 3394083 358652 359364	Tub Ring) Foot, Front (2) Foot, Rear (2) Clip, Front Panel Link, Leveling Clip, Leveling Mechanism (2)
25 26 27	98234 345670	Clip, Ground Lock, Top (2) Panel, Front White
28 31 32	692628 692629 690989 3350013 64247	Almond Screw, Ground Foam (2) Screw


#### BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Models: LTG5243DQ0, LTG5243DZ0 (Designer White) (Designer Almond) Illus. **Part** Illus. **Part DESCRIPTION** No. No. No. No. **DESCRIPTION** 1 3357334 Screw, 387948 Brake And 10 Drive Tube (3) (Gearcase (Complete) To Tub Support) (Refer To Page 62611 Plate, Motor 11 16 For Further Mount To Breakdown) Gearcase 2 63292 Washer, Spin 13 3364003 Coupling, Motor Tube Thrust & Isolating 3 62697 Ring, Spin 661600 Motor, 14 Main Drive Tube Support 3355454 Clip 63283 Ring, Retainer 4 15 3351342 Clutch (Complete) 5 (Anti-Rattle) 6 3946793 Band and Lining 3946532 Plate, Motor 16 (Includes Illus. 3363394 Pump, Complete 18 62700 Retainer, Pump 7 & 8) 19 3364271 Spring, Clutch 62646 Cap, Clutch 7 62850 Switch, Main 20 8 **Drive Motor** Spring (2) 21 62691 Grommet, 3360630 Gearcase 9 Motor (4) (Complete)(Refer 22 3349637 Retainer. To Page 15 For Motor (2) 15 Further 24 3387485 Screw, Breakdown) 10-16 x 5/8 (2) 10 9 10 22 24 11 21 13 16 19


18 19

22

#### **MACHINE BASE PARTS**




# **TUB AND BASKET PARTS**




Illus. No.	Part No.	DESCRIPTION
1	3355758	Cap, Agitator
2	358237	Screw & Washer (5/16–24 x 1)
3	63840	
3 4	3349098	
5	64175	Tub Ring &
		Gasket (Includes Illus. 7, 14 & 15)
6	21366	
7	3359587	
		Tub Ring
8	3351985	Basket
9	63782	Tub
10	389140	
		Basket Drive
11	696238	Hose, Pressure
		Switch
12	371502	Clamp, Hose
13	386929	Hose, Tub
		To Pump
14	352155	Clip, Retaining
		(2)
15	356398	Tube,
		Drain Off
16	357640	Screw & Washer
		(Tub Mounting)
		(4)
17	383727	Gasket,
		Centerpost

#### **WASHER WATER SYSTEM PARTS**




#### **GEARCASE PARTS**



# **BRAKE AND DRIVE TUBE PARTS**

For Models: LTG5243DQ0, LTG5243DZ0
\_\_\_\_\_(Designer White) (Designer Almond)




No.	No.	DESCRIPTION
1	387948	Brake And Drive Tube
2 3 4 5	62658 91939	(Complete) Ring, Thrust Seal, Oil
4	356427	Seal, Drive Tube
5	356937	Spacer, Drive Tube
6	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8 9	64232	Brake Shoe
9	62703	"T" Bearing, Spin Tube
10	62648	Cap, Brake Spring (2)
11	63748	Spring, Brake
12	62909	Sleeve, Brake Spring
13	661516	Cam, Brake Release 63023 (Alt.) 3348288 (Alt.)
14	63022	Sleeve, Cam
15	64194	Driver, Brake Cam
16	90368	Ring, Retaining

BD-313B


# **SALES ACCESSORY PARTS**

For Models: LTG5243DQ0, LTG5243DZ0 (Designer White) (Designer Almond)

# **LCK 4500**




Illus. No.	Part No.	DESCRIPTION
1	694609	Exhaust Deflector Kit (Complete)
2	687128	Screw, Mounting (2)
		(10–16 X 1/2) (Hex Washer Head)
3	279823	Side Exhaust Extension Kit
		(Complete)
4	488729	Screw
5	3395536	Clip



# **MISCELLANEOUS PARTS**

For Models: LTG5243DQ0, LTG5243DZ0 (Designer White) (Designer Almond)




#### LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
LITE	RATURE	PARTS			OPTIONAL PAI	RTS NOT	INCLUI	DED
L	_IT3401098	Instructions, Installation Guide, Use & Care Label, Wiring Diagram	<b>PAIN</b> 72017		White Almond	OIL	350572	Oil, Gearcase (16 Oz.)
l	LIT3397739		(13 oz	350938 350930	B Primer, Gray White Almond	LUBR	285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)
				978883 <b>ESSOR</b> 692790	White (Uncut) Almond (Uncut)  Y PARTS  Plug, Dryer Side Panel White Almond	SEAL		Sealer, Gasket (.20 Fl. Oz.) (6 ml)

#### 3401796 BURNER ASSEMBLY

For Models: LTG5243DQ0, LTG5243DZ0 (Designer White) (Designer Almond)

# USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED, TYPE 3 – MANUFACTURED AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES



Illus	. Part		Illus.	Part	-	Illus	. Part	<del>_</del> _
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	3401796	Burner Assembly 60 Hz.	9	694421	Screw, 8-32	22 23	697441 3388638	Valve, Shutoff Nipple, Short
2	697408	Base, Burner	10	694538	Bracket, Shunt	24	3391118	Supply Line
3	3401777	Valve, 60 Hz.	11	694422	Spring, Regulator			(Gas)
4		Orifice	12	239822	Pipe, Plug	25	233076	Nut
	234822	Natural Gas	13	694423	Screw	26	3393767	Pipe
	347743	L.P. Gas	15	3392268	Burner			
5	3401849	Harness	16	3387057	Screw, 8-18 X 3/8	Fol	lowing Pa	arts Not Illustrated
6	694539	Coil, 60 Hz.	17	686590	Ignitor			
		(Split)	18	3393909	Screw and Washer		694580	Conversion Kit
7	694540	Coil, 60 Hz.			8–32 x 1		00 1000	(Type 1, 2 & 3)
8	694424	Leak Limiter	20	697409	Bracket, Sensor			to Type (4) L.P.G.
			21	338906	Sensor, Radiant			to Type (1) 2.1. 10.